

PUMP OUT STATION -- INSTRUCTIONS ON USE

Mon - Fri Contact: - 8:30 a.m. – 4:30 p.m.- 301-475-9791


After hours: Message Leonardtown Wharf Facebook
Messenger (*someone will respond if available*)

Determine which color hose will be used for the use of operation

USE OF YELLOW HOSE – STATIONARY OR USE OF GREEN HOSE - PORTABLE

1. Determine which color hose is required to be used for the pump-out - **GREEN OR YELLOW**
2. If the **YELLOW HOSE** is to be used, assure that the valve with the blue handle at the green hose is in the perpendicular position which is **OFF**.
3. If the **GREEN HOSE** is to be used assure that the yellow valve for the yellow hose is in the **OFF** position. Turn **ON** the blue valve located by the green hose to the **ON** position.
4. On the power pedestal - Push the green start button on the power pedestal (green button) to start the unit. The unit needs time to build up pressure to 20hg before the unit will start drawing. You will not hear anything run but, you will start to hear suction after the vacuum has built up pressure.
5. Once the suction is complete, flush toilet to allow fresh water to flush system.
6. Once pump is done, flush the toilet to allow clean water to flush the system

To use **GREEN HOSE**,
YELLOW HOSE must be
in the **OFF** position



The **BLUE HANDLE** valve in the photo represents the **OFF** position

